

BioLogic mini Set Up and Replacement Guide

1



Position the device on a surface

2



Grip the base and the cap of the device

3



Turn the cap counterclockwise

4



Remove the cap

5



Open the ENVIROBIOTICS bottle, keep upright

6



Place the device over the bottle

7



Screw the bottle into the base until tight

8



Turn the device over and place on a surface

9



Put the cap on the device, turn clockwise

10



The device is ready, please read the operating instructions

Operations

The BioLogic mini has two operating modes - **Automatic** and **Spray**.

Automatic mode (emits a short burst hourly)

This is the default mode for your BioLogic mini which provides 24/7 automatic and continuous operation. Your ENVIROBIOTICS refill should last between 11-12 weeks in automatic mode.

Spray mode

Spray mode is for when you would like to apply an immediate, heavier fogging to a contaminated area. When you press the [Spray] button, the device will continuously disburse ENVIROBIOTICS for 30 seconds. After the 30 seconds the device automatically returns to Automatic Mode. When spraying, hold the device upright, and make sure to spray over any area or object you would like to cover. Effective in any space!

Shutting down the device

Press and release the power button quickly. You will hear two short beeps, the LED will go out, and the device will be off.

LED color indications

Steady Blue: the device is in automatic mode

Steady Green: indicates the device is dispersing ENVIROBIOTICS.

Low Liquid LED when lit indicates low liquid level, and a beep will be activated.

Battery LED when lit orange indicates recharging required. When lit white indicates battery fully charged.

Charging The BioLogic mini

Connect the USB charging cord to the device, and charge for two to three hours until the battery indicator LED is white.



Night Mode–Turning off all LED Displays:

Enter and Exit the Night Mode by holding the power button for three seconds. There will be three short beeps and three flashes of the blue LED to confirm Entry or Exit.

Night Mode will disable all LED's for ten hours while all other functions still operate. The BioLogic mini repeats the Night Mode daily until it is disabled.

Follow the refill replacement procedure.



www.EnviroBiotics.com



ENVIROBIOTICS
ENVIRONMENTAL PROBIOTICS

BioLogic Mini

Probiotic Purification for Surfaces, Objects & Air

Quik Start Guide