BioLogic mini-first use and refill guide.

The Only technology for total protection of the entire indoor space



Place device and refill on a surface



Turn the device over the bottle



Hold the base and the cap

Keep unit and bottle

vertical while screw the



Turn the cap counterclockwise



unscrew the empty bottle. Carefully unscrew the refill bottle-cap



Flip the device on the new bottle



Flip device as shown, reattach cap



Close the cap clockwise



Device is ready.
Follow instructions
on your right

Operations

The device is a dual-purpose dispersion system:
A rapid, light touch of the power button enables the selection of operation modes.
The Green LED should flash once before entering mode one and twice for mode 2

Mode 1: Continuous dispersion

The device operates as an electronic fogger where a fast cleaning of contaminated areas is desired. Fog the area for about 30 seconds by pointing the device vertically to the floor in all directions of your room/vehicle/office.

Mode 2: Automated mode

24 X 7 continuous, automatic protection of your space.
The device should momentarily disperse only once an hour for a few seconds
Using Mode 2 alone - the refill should last about 11-12 weeks.

Shutting down the device

Continued long press the power button for about 3 seconds.
The LFD color should turn blank.

LED color Indications:

- O Green device disperses
- O Blue Idle between dispersion
- Red Recharge device connect to the device the supplied C-type cable to a certified USB charger (not supplied)
- O Blue & Red The device is properly recharging.

When LED is Green, but the device does not disperse, the refill's tank is empty. REPLACE REFILL







Follow the refill replacement procedure.



www.better-air.com





BioLogic mini

The Only technology for total protection of entire indoors space

SURFACES | OBJECTS | AIR



Protects the indoors from contaminants and allergens



Reduces use of chemicals and detergents



estores Ecological Balance to our environments



Reduces bad odor